



Installation Instructions

1. **Ensure your vehicle's ignition is off with the key removed.**
2. Remove the original Head Unit (radio) with reference to the manufacturer's instructions.
3. Assemble the Patch Lead (**NOT SUPPLIED IN 29-702**) so that it is compatible with the Head Unit being installed.
4. Connect the patch lead to the new Head Unit and then to the Steering Control Interface (**Black box on 29-702 harness**). **THIS MUST BE DONE FIRST BEFORE ANY OTHER CONNECTIONS.**
5. Remove the connectors from the rear of the original head unit.
6. Connect the grey connector of the **29-702** harness to the connector just removed from the original Head Unit.
7. **LOCATE THE 32 PIN GREY CONNECTOR**, connect the loose **White to pin 4** and **Purple to pin 20**.
8. Fit the iso connectors to the new head-unit wiring.
9. Test the system fully ensuring all controls function before refitting the new Head Unit.